MANUAL USE AND CLEANING Toy shovel – LEPALE KIDS



NBS – TEC Sagl , via cantonale , 6573 Magadino - Ticino – Switzerland www.lepale.ch - info@lepale.ch



Before beginning any activity with the toy it is necessary for the adult in charge of supervising the child for whom the toy is destined, to have read and understood the full manual.

- CAUTION: The product must be used by children accompanied by an adult. Adult supervision is always necessary during gameplay
- CAUTION: There is a risk if the cardboard and plastic wrapping are swallowed if folded or cut inappropriately
 by the child and ingested by mouth there is danger of suffocation. It is necessary to keep the cardboard
 packaging and plastic wrapping of Lepale Kids spade out of the reach of children and to dispose of them in
 accordance with current regulations regarding recycling.
- Check immediately that the product is in perfect condition. If there are any damages, missing parts, deformation or scratches due to transport, contact NBS Tec Sagl before proceeding with successive operations.
- Lepale KIDS is a toy destined for children from the ages of 2-14 years old.
- Do not leave the spade near heat sources.
- Do not put the spade near flammable sources.
- Avoid putting the package or the spade in contact with sharp edges and abrasive surfaces.
- Evitare che la confezione e la paletta entrino in contatto con spigoli appuntiti e superfici abrasive.
- **DISPOSAL**: This product is subject to recycling at the end of it's lifespan. Do not for any reason throw the product away in mixed waste bins. Refer to current regulations for the disposal of plastic waste.

Description of the toy.

The cardboard box contains: one kid's spade and a safety manual.

The spade is made from food polymers.

With Lepale KIDS the perfect way of digging is represented by it's functionality, innovation and easy usability.



NOTE

NBS Sagl cannot be held responsible for accidents or damages caused by the inappropriate use of the product or by non observance, even partially of the safety standards and intervention procedure described in the booklet.

Usage

Lepale KIDS is usable only with soft and/or smooth materials, e.g. sand, soil, snow etc.

Everything that can be done can be found on www.lepale (doc. plus kid's video).

Cleaning and storage

Clean the product parts delicately with a dry cloth to remove dust and dirt. You can also use a damp cloth with a neutral detergent to clean it.

Caution:

Do not use solvents or abrasive detergents.

When not being used, store the product in a box, (also the original one), away from direct light and weathering, heat sources and dust.

Residual risks

In the design phase, NBS Tec Sagl, has done an in depth risk analysis of this toy. In this analysis unavoidable risks by their nature, emerged. These risks have therefore been addressed singularly in this manual and the instructions on how to avoid them have been emphasized



NOTE

The manufacturing company cannot be held in any way responsible for accidents or damages caused by unintended uses as a result of negligence by the user.

- On delivery check the state of the package and verify that there is no trace of damage, scratches, dirt, mould etc.. that could have been caused during transport and or inappropriate storage. In this case contact the manufacturing company (see Manufacturing data).
- Before allowing the child to play it is necessary for an adult to verify the structural integrity. If it has been damaged, broken or has any protruding parts, it is absolutely forbidden to give the toy to the child.
- The game is not adapt and cannot be used by children under 24 months. This is also indicated on the product's label
- If the child is allowed to unwrap the plastic packaging, the supervision of an adult is necessary. The adult must then dispose of the plastic wrapping immediately so that the child is not able to play with it.
- Dispose of the plastic wrapping respecting local regulations for the disposal of plastic waste.
- To make sure that the toy doesn't accumulate dirt and bacteria it is necessary to clean it regularly. In this
 manual there is a paragraph dedicated to this. (see Cleaning and storage).
- Before allowing the child to play, clean the toy with a neutral detergent.

Disposal

After removing the plastic packaging around the box it must be discarded in recycling waste bins in accordance with current regulations. The cardboard box must be discarded in recycling waste bins in accordance with current regulations. The spade must be discarded in plastic recycling waste bins and in the condition that it can no longer be used for the scope for which it was projected and made, thus making the prime materials that it is made from reusable.

Do not discard under any circumstances the packaging or the product into the environment.



NOTE

The manufacturing company is in no way responsible for any damages caused by the toy if not used in the full version and for the use and mode specified in this manual. The manufacturing company is no no way responsible for any damages to people or things derived from the recuperation of the toy parts used after disposal.